

Original Assembly and Maintenance Instructions

Linear Unit

HSB-delta®

Types

Delta 90-SRS

Delta 110-C-SSS

Delta 145-C-SSS

Delta 200-SSS

Delta 240-SSS

Delta 240-C-SSS

Contents

1	Safety	2
1.1	Symbols used	2
1.2	Regulation use	2
1.3	General safety	3
1.4	Use in clean rooms	3
1.5	Use in explosive environments	3
1.6	Technical condition of the linear unit	4
1.7	Modifications to the linear unit	4
1.8	Requirements for personnel	4
1.9	Obligations of the operating company	5
2	Warranty	6
3	Technical data – Standard model	7
4	Product description	12
5	Transportation and storage	15
6	Installation and adjustment	16
6.1	Installing the linear unit by mounting rails	16
6.2	Screwing the linear unit into place from below	17
6.3	Setting maximum travel	17
6.3.1	Setting the positions of the inductive limit switches	18
6.3.2	Setting the positions of the mechanical limit switches	19
6.4	Mounting a drive unit	20
6.4.1	Mounting a motor	21
7	Start-up	22
8	Operation	23
9	Shutdown	23
10	Maintenance	25
10.1	Lubrication	25
10.2	Replacing cover bands	29

1 Safety

This operating manual is an integral part of the machine package, and must be kept permanently ready to hand as a reference source. It must be passed on with the machine if the machine is sold on.

If there is anything in this manual which you do not fully understand, please be sure to contact the manufacturers.

1.1 Symbols used

This manual employs the following symbols to indicate hazards as well as other types of symbol:

DANGER



Indicates immediate danger.
Failure to observe this notice entails risk of death or very serious injury.

WARNING




Indicates a danger carrying a medium to high risk.
Failure to observe this notice may result in death or serious injury.

CAUTION



Indicates minor risk.
Failure to observe this notice may result in light to moderate injury or damage to property.

 Note

Indicates tips on use of the machine and optimising its efficiency.

1.2 Regulation use

The mechanical linear unit is intended to be used solely for manipulating, positioning, transporting, palletising, loading, unloading, clamping, clocking, tensioning, testing, measuring, handling and pushing workpieces or tools.

Pay attention to the basic applications of the linear unit set out in sections 4 and 3.

In order to comply with the EU Directive governing Electromagnetic Compatibility (EMC), the mechanical linear unit may only be used in industrial environments, as defined in European standard EN 61000-6-1.

Any other use, or use for purposes beyond those stipulated, will be classed as illegitimate. The manufacturers accept no liability for any loss thereby incurred. The risk is borne solely by the operators.

1.3 General safety

Preconditions for operation

The linear unit must not be put into operation until the machine or line into which it is installed conforms to the following:

- Relevant accident prevention regulations
- Generally accepted safety standards
- EU directives
- Standards governing the electromagnetic compatibility of machinery
- Other applicable standards
- Applicable national legislation.

Safe operation

To ensure safe operation, refer to the following documents:

- This operating manual for the linear unit, particularly the technical data
- The operating manual for the line into which it is installed

1.4 Use in clean rooms (ISO 14644)

The linear units used in clean rooms are fitted with a vent hole (generally G1/4") at the basic profile.

The following guidelines must be observed:

- The linear unit must be subjected to a negative pressure of 0.2 bar.
- The linear unit must be relubricated with a grease suitable for use in clean rooms (basic lubrication carried out using Klübersynth BEM 32-34).

1.5 Use in explosive environments



The linear units are suitable for use in potentially explosive atmospheres, but the supplement to these assembly and maintenance instructions "[FM_319_Use-in-Atex-zones-MuW](#)" must be observed.

1.6 Technical condition of the linear unit

State of the art

The unit conforms to the current state of the art and applicable rules and regulations. The unit conforms to the EU Machinery Directive and the harmonised standards (European standards). Furthermore, the EC Declaration of Incorporation applies:

- EN ISO 12 100-1 and 12 100-2 Safety of machinery, equipment and plant
- DIN EN 418: Safety of machinery; emergency-stop devices
- DIN EN 60,204: Electrical equipment for industrial machines
- EN 61000-6-1, EN 61000-6-3: Electromagnetic compatibility (EMC)

1.7 Modifications to the linear unit

Modifications

The linear unit must not be modified, either in its basic design or in its safety components, without our written consent. Any such unauthorised modification will void our liability in respect of the unit.

The operating company may only carry out the maintenance and repair work detailed in this operating manual. Any other measures, such as to replace wearing parts and components, may be carried out only in consultation with our service engineers, by the service engineers themselves, or by us directly.

Installed safety devices must never be dismantled or disabled.

When fitting special attachments to the unit, follow the fitting instructions provided by the manufacturers!

1.8 Requirements for personnel

The linear unit has been designed and built in accordance with the state of the art and accepted safety standards. Hazards may nevertheless be posed when operating it. Consequently, the unit may only be installed and operated by trained, competent personnel.

All personnel assigned to install, operate, maintain, repair or dismantle a linear unit must have read and understood this operating manual, and in particular section 1, "Safety".

Work on parts carrying live electrical current may be carried out only by trained electricians. Such work includes:

- Installing safety limit switches
- Mounting a drive unit
- Checking the direction of rotation of the drive

1.9 Obligations of the operating company

Instruction of personnel	<p>In accordance with EU Health and Safety Directive 89/655/EEC articles 6(1) and 7 and with the Framework Directive 89/391/EEC articles 1(1) and 6(1), the company operating the linear unit must provide personnel assigned to install, operate, maintain, repair or dismantle the unit with appropriate instruction, in particular with regard to safety.</p> <p>We recommend that companies require their personnel to provide written confirmation of having received such instruction.</p>
Checking the unit	<p>In accordance with EU Health and Safety Directive 89/655/EEC article 4a, the operating company must subject the unit to thorough checking prior to putting it into operation, after carrying out repairs, and after malfunctions have occurred.</p>
Legibility and maintenance of affixed notices and labels	<p>The operating company must ensure that all notices and labels attached to the unit are fully legible (in particular details of the serial number) and must ensure compliance with all instructions contained on them. Damaged or illegible notices and labels must be replaced.</p>

2 Warranty

The warranty conditions are laid down in the terms and conditions of delivery and payment issued at time of order. Warranty cover will be voided if:

- the unit is not operated in accordance with the stipulated regulation use;
- the instructions set out in this operating manual are not followed;
- the unit is modified without the consent of the manufacturers;
- screws sealed by locking varnish are unlocked.

The manufacturer's warranty in respect of maintenance and repair work applies only if original replacement parts are used.

3 Technical data – Standard model

Linear unit model Delta	Sizes			
	90		110-C	
	SRS		SSS	
Drive element	BSD ²⁾	TSD ³⁾	BSD ²⁾	TSD ³⁾
Max. speed [rpm]	3000	1500	3000	1500
Spindle diameter [mm]	12	12	16	16
Spindle pitch [mm]	5 10	3	5 10 20 40	4
Moment of inertia [kgm ² /m]	1,20 x 10 ⁻⁵		3,25 x 10 ⁻⁵	
Max. velocity ¹⁾ [m/s]	0,25		2	
Max. acceleration [m/s ²]	20		20	
No-load torque [Nm]	0,30		1,0	
Maximum travel (standard) [mm]	1245		5370	
Length of standard/long carriage [mm]	160 / 240		145 / 265	
Repeat accuracy [mm]	±0,03 (BSD)		±0,03 (KGT)	
Operating temperature [°C] (continuous operation)	0 ... 80		0 ... 80	
Geometrical moment of inertia I _y [mm ⁴]	223339		446420	
Geometrical moment of inertia I _z [mm ⁴]	1195788		2505144	
Weight (without travel) [kg]	3,25		11,0	
Weight (per 100 mm travel) [kg]	0,47		0,9	
Weight of standard carriage [kg]	1,30		2,3	
Weight of long carriage [kg]	1,85		3,25	
Noise emission max. [dB A] ⁴⁾	75		75	

¹⁾ Dependent on spindle pitch at max. speed

²⁾ Ball Screw Drive

³⁾ Trapezoidal Screw Drive

⁴⁾ The figure will vary based on assembly with other system components


Linear unit model Delta	Sizes			
	145-C	200	240	240-C
	SSS	SSS	SSS	SSS
Drive element	BSD ²⁾	BSD ²⁾	BSD ²⁾	BSD ²⁾
max. speed [rpm]	3000	3000	3000	3000
Spindle diameter [mm]	20	32	32	32
Spindle pitch [mm]	5	5	5	5
	10	10	10	10
	20	20	20	20
	50	40	40	40
Moment of inertia [kgm ² /m]	8,50 x 10 ⁻⁵	6,45 x 10 ⁻⁴	6,45 x 10 ⁻⁴	6,45 x 10 ⁻⁴
Max. velocity ¹⁾ [m/s]	2,5	2	2	2
Max. acceleration [m/s ²]	20	20	20	20
No-load torque [Nm]	1,0	2,8	2,8	2,8
Maximum travel (standard) [mm]	5275	3620	2600	5400
Length of standard/long carriage [mm]	180 / 300	250 / 400	280 / 400	280 / 400
Repeat accuracy [mm]	±0,03 (BSD)	±0,03 (BSD)	±0,03 (BSD)	±0,03 (BSD)
Operating temperature [°C] (continuous operation)	0 ... 80	0 ... 80	0 ... 80	0 ... 80
Geometrical moment of inertia I _y [mm ⁴]	1251254	3889990	6369119	4944409
Geometrical moment of inertia I _z [mm ⁴]	7737207	28139811	59788355	38449888
Weight (without travel) [kg]	10,8	22	26	18,8
Weight (per 100 mm travel) [kg]	1,5	2,6	3,4	3,3
Weight of standard carriage [kg]	4,9	8,4	10,2	10,2
Weight of long carriage [kg]	6,5	11	14,6	14,6
Noise emission max. [dB A] ⁴⁾	75	75	75	75

¹⁾ Dependent on spindle pitch at max. speed

²⁾ Ball Screw Drive

³⁾ Trapezoidal Screw Drive

⁴⁾ The figure will vary based on assembly with other system components

	Forces and moments - Delta linear unit with spindle drive							
Type designation	Dynamic forces [N]				Dynamic moments [Nm]			
	F_x	F_y	F_z	$-F_z$	M_x	M_y	M_z	$M_{no-load}$
Delta 90-SRS	1000	500	1000	1000	60	80 (110)	80 (110)	0.3
Delta 110-C-SSS	2000	1200	3000	1500	500	550 (1000)	550 (1000)	1.0
Delta 145-SSS Delta 145-C-SSS	6000 4000	2500	5000	3000	800	1000 (1600)	1000 (1600)	1.1 1.0
Delta 200-SSS	10000	5000	8000	5000	3500	4300 (6000)	3200 (4500)	2.8
Delta 240-SSS	12000	6000	12000	8000	4500	6000 (8500)	4500 (6400)	2.8
Delta 240-C-SSS	12000	6000	12000	8000	4500	6000 (8500)	4500 (6400)	2.8

Figures in () relate to the long carriage.

$M_{no-load}$ = No-load torque $\pm 30\%$

The forces and moments quoted are maximum values for the single load. In the event of combined loading or simultaneous occurrence of multiple moments or forces, the individual values must be reduced. In case of doubt consult Technical Support.

Dynamic load ratings of rail guides - linear unit Delta SSS

(THK and Rex = Rexroth)

Model	Size	Number of rails	Number of carriages	Load rating per carriage C_{dyn} [N] THK / Rex	Pre-tension F_v THK / Rex	Guide spacing in direction x (l_{x1}) [mm]	Guide spacing in direction y (l_y) [mm]
Delta 110-C	15	2	4	11271 / 9860	564 / 620	75 (195)	66
Delta 145-C	20	2	4	17700 / 23400	885 / 1500	87 (207)	87
Delta 200	25	2	4	25160 / 28600	1258 / 1820	144 (294)	126
Delta 240 Delta 240-C	25	2	4	25160 / 28600	1258 / 1820	159 (279)	150

Figures in () relate to the long carriage

The load rating and pre-tension figures relate to the standard linear guidance system with recirculating linear ball bearings

Dynamic load ratings of ball screw drives - Delta linear unit

Model and size	Nominal Ø in [mm]	Pitch in [mm]	C _{dyn} [N]
Delta 90	12	5	3800
		10	4300
Delta 110-C	16	5	12800
		10	14300
		20	8100
		40	8500
Delta 145-C	20	5	14600
		10	13500
		20	11500
		50	12300
Delta 200	32	5	26200
		10	33100
		20	30200
		40	15200
Delta 240 Delta 240-C	32	5	26200
		10	33100
		20	30200
		40	15200

Dynamic load rating of ball screw nut to DIN 69051, 1989

Static and dynamic load ratings of roller guides - linear unit Delta SRS

Model	Size (\varnothing) [mm]	Number of load- bearing rollers for Fz	Number of load- bearing rollers for Fy	Load rating per roller C _{stat} [N]	Load rating per roller C _{dyn} [N]	Guide spacing* in direction x [mm]		Guide spacing in direction y [mm]
						lx1	lx2	ly
Delta 90	20	4	2	600	1.500	100 (180)	100 (180)	54.5

The pre-tension per roller is approximately 5%

Tightening torques [Nm] for fixing screws

Fixing screws	M4	M5	M6	M8	M10	M12	The figures given are intended as guides. For shorter insertion depths, the figures must be adjusted accordingly.
DIN912/ISO4762-8.8	2,7	5,4	9,0	22,0	43,0	74,0	
DIN912/ISO4762-10.9	3,0	5,7	9,0	22,0	43,0	74,0	
DIN912/ISO4762-12.9	3,0	5,7	9,0	22,0	43,0	74,0	

Tightening torques [Nm] for clutch with clamping hub


Size	14	19	24	28	38
Clutch diameter [mm]	30	40	55	65	80
Screw size	M3	M6	M6	M8	M8
Tightening torque [Nm]	1.34	10.50	10.50	25.00	25.00

Tightening torques [Nm] for clutch with clamping ring hub

Size	14	19	24	28	38
Clutch diameter [mm]	30	40	55	65	80
Screw size	M3	M4	M5	M5	M6
Tightening torque [Nm]	1.34	2.90	6.00	6.00	10.00

4 Product description


**Linear unit with
spindle drive and
roller guideway or
rail guidance**



Key	1	Stripper brush	7	Driver
	2	Carriage	8	Nut driver
	3	Cover band	9	Base profile
	4	Lubricating nipple	10	Drive bearing
	5	Movable bearing	14	<u>Centre bar</u>
	6	Spindle		

Figure 1: Component assemblies of Delta 90 (above) and Delta 200 linear unit with spindle drive

**Guide elements
roller guideway and
rail guidance**



Key	9	Base profile	13	Roller guideway
	11	Guide rail		
	12	Recirculating ball bearing		

Figure 2: Rail guidance of Delta 90 (above) and Delta 200 linear unit

A mechanical linear unit converts rotational motion into linear motion and is used to move loads quickly, safely and precisely from one position to another. It consists of an aluminium base profile, a moving carriage supported by a guide element (recirculating ball bearing guidance system) and a drive element (screw or timing belt drive).

Depending on its design, the carriage is able to absorb forces and moments in all directions, and is positively connected to the guidance and drive elements by way of the so-called drivers.

The base profile is self-supporting up to a certain length, and is equipped with grooves for mounting.

As an option, the linear unit can be equipped with accessories such as screw supports, inductive or mechanical limit switches and other fittings (see section **6.3**).

The effective range can be flexibly configured. Multiple linear units of the Alpha, Beta or Delta type can be arranged two-dimensionally (2 axes) or three-dimensionally (3 axes).

Driven linear units can be connected to non-driven units of the same type by a plate, to be able to take large-area loads for example.

5 Transportation and storage

The mechanical linear unit is a precision item. Its mechanism may be damaged by heavy jolting, resulting in impairment of its functions.

CAUTION



Risk of damage by heavy jolting or deformation!

Transport the assembled linear unit only with the transportation safety fixtures attached.

To prevent damage during transportation and storage, protect the linear unit against shaking and sliding as follows:

- Stow it in a box of sufficient size.
- Use packing.

Section 3 lists the unit weights.

Protect the unit against:

- dirt;
- corrosion;
- water;
- and aggressive atmospheres.

6 Installation and adjustment

The linear unit can be attached by the following methods:

- On mounting rails
- By screws inserted into the sliding blocks
- By screws inserted into the factory-fitted tapped hole rails

✎ Install the linear unit on a flat surface. Unit parallelism $<0.2 \text{ mm}/1000 \text{ mm}$.

✎ Mounting by the rails with tapped holes in them is the preferable solution:
for highly dynamic applications;
where the linear unit has only two attachment points.

6.1 Installing the linear unit by mounting rails




Figure 3: Mounting rails (1)

✎ The recommended maximum spacing between the mounting rails is 700 mm.

Procedure

1. Attach the mounting rails (1) loosely in position (Figure 3).
2. Align the linear unit axially.
3. Tighten the mounting rails (1)
(for tightening torques see section 3).

6.2 Screwing the linear unit into place from below (not Delta 90)




Figure 4: Sliding blocks (1) in the groove on the underside of the base profile

Attach the linear unit by the fixing screws from below using the sliding blocks or the tapped hole rails in the aluminium base profile (Figure 4).

Procedure

1. Align the linear unit.
2. Align the sliding blocks (1)/tapped hole rails.
3. Tighten the linear unit
(for tightening torques see section 3).

6.3 Setting maximum travel

DANGER



Serious injury may result if the transport carriers topple over. If the carriage moves to its full extent beyond the safety zone, the transport carrier mounted on it may break away or topple over. The linear unit may be destroyed.

Keep to the specified safety zone when setting up the unit, and set the limit switches accordingly.


Electrical switches may only be connected by qualified electricians.

☛ To stop the carriage promptly in the event of an emergency stop, allow for adequate braking distance.

6.3.1 Setting the positions of the inductive limit switches

The function of inductive proximity switches is to shut down the electric drive before the mechanical end position is reached.

The necessary braking distance (ΔB) depends on the velocity and deceleration of the carriage. The braking distance must be between the switching point of the proximity switch and the actual mechanical end position.



Key	1	Inductive limit switch
	2	Switching cam
	3	Band marking safety zone

Figure 5: Inductive limit switches

CAUTION



The limit switches must switch so that the carriage comes to a stop immediately before the safety zone. The safety zone is factory-marked on the unit by a band (3).

Procedure

1. Connect the power to the limit switches.
2. Slacken the limit switch fixing screws.
3. Run the carriage as far as the braking position.
4. Move the limit switch (NC contact) under the switching cam until it trips and the LED on the sensor goes out.
5. Move the carriage away.
6. Tighten the limit switch.
7. Check the correct position of the limit switch: Move the carriage manually and observe the switching operation.
8. Fit the limit switch array covering.

6.3.2 Setting the positions of the mechanical limit switches


Mechanical safety limit switches (NC contacts) must be used if a hazard is posed to personnel as soon as the electric drive fails to shut down.

The drive may only be started up when all limit switches are connected and correctly set!

A combination with inductive proximity switches is possible.

External shock-absorbers must be fitted to protect against mechanical destruction.

The necessary braking distance (ΔB) depends on the velocity and deceleration of the carriage. The braking distance must be between the switching point of the limit switch and the actual mechanical end position (Figure 6).



Key	1	Mechanical limit switches
	2	Switching cam
	3	Band marking safety zone
	4	Bracket
	B	Braking distance

Figure 6: Mechanical limit switches

CAUTION


The limit switches must switch so that the carriage comes to a stop immediately before the safety zone. The safety zone is factory-marked on the unit by a band (3).

Procedure

1. Connect the power to the limit switches.
2. Slacken the bracket fixing screw (Figure 6).
3. Run the carriage as far as the safety zone.
4. Move the limit switch until it trips.
5. Tighten the bracket fixing screw.
6. Check the correct position of the limit switch: Move the carriage manually and observe the switching operation.
If the braking distance is too short, repeat the set-up.

6.4 Mounting a drive unit


Make sure the direction of rotation of the external drive unit takes into account the direction of the spindle or timing belt so that the limit switches work correctly.



Key	1	Safety zone	3	Carriage with positive and negative directions from reference point 0
	2	Negative limit switch	4	Positive limit switch

Figure 7: Example of travel direction and limit switch configuration

6.4.1 Mounting a motor



Key	1	Clutch half 1	4	Motor housing
	2	Clutch ring	D	Diameter on motor housing
	3	Clutch half 2		

Figure 8 Motor housing with motor clutch on drive pin

Procedure

1. Place the motor and the clutch components in mounting position adjacent to the linear unit.
2. Check the direction of rotation of the motor. It must take into account the safety limit switches (Figure 7). Alter the direction of the motor as necessary.
3. If the clutch diameter is less than the measure D on the motor housing (4), first mount clutch half 1 (1) (drill hole flush with drive shaft) and then the motor housing (4) (Figure 8).

If the clutch diameter is greater than the measure D on the motor housing (4), first mount the motor housing (4) and then clutch half 1 (1) (drill hole flush with drive shaft). Tighten the clutch clamping screw through the mounting hole on the motor housing (4).

4. Slot the clutch ring (2) onto the clutch.
5. Mount clutch half 2 (3) on the motor pin.
6. Mount the motor on the motor housing.

Tightening torque [Nm] of clamping screws

Screw	SW	Torque
M6	5	14
M8	6	35
M10	8	65
M12	10	74

7 Start-up

WARNING



Risk of injury to personnel or damage to other components due to the high-speed linear motion of the transport carrier by the load being thrown off.
Only authorised technical personnel may operate the linear unit.

WARNING



Risk of crushing if the transport carrier is moved in the wrong direction. If the directions of rotation of the drive (motor or gearbox) and of the carriage drive (spindle or timing belt) do not match, the mounted transport carrier may move in the wrong direction.
Only qualified electricians may carry out electrical installation and check rotation.

Checks before start-up

Before starting the unit, check the following:

- Make sure the retaining fixtures conform to the mass and acceleration data provided by the manufacturers.
- Make sure the machine or line into which the linear unit is installed conforms to the EU Machinery Directive, the harmonised European standards or applicable national standards.
- Make sure the linear unit is correctly installed.
- Make sure the inductive and/or mechanical limit switches are correctly connected and working properly.
- Make sure the direction of rotation of the motor shaft and - where appropriate - of the interposed gearbox - matches that of the spindle or timing belt.

If the checks reveal any defects, prohibit start-up of the unit.

Trial run

To prevent accidents, collisions and possible errors in the programming, move the linear unit along the stroke several times at such a low speed that it can be stopped in good time in case of an emergency.

The line may be started up once it has been established that there is no risk of collision when the maximum travel is overrun.

8 Operation

CAUTION



Risk of damage from harmful environmental influences!
Operate the linear unit only under the ambient conditions approved by the manufacturers.

Ambient conditions

Operate the linear unit only within the permissible temperature range of 0 ... 80 °C.

If the linear unit is operated in moist, abrasive medium, foreign bodies may penetrate it. To prevent that, the operating company must take appropriate measures to prevent intrusion of foreign bodies, such as by installing deflectors, baffle plates or air barriers.

Duty of inspection

The proper functioning of the linear unit must be checked periodically during operation.

The responsible personnel must check the linear unit and the line for external signs of damage and defects at least once every shift.

If changes occur which are detrimental to safety, shut down the line immediately.

Emergency stop

The maximum permissible load values must not be exceeded even in an emergency stop situation.

As a rule, the category 1 emergency stop strategy (targeted braking to standstill, then de-energise) is chosen for automation equipment with moving masses. A simple emergency stop strategy is not usually effective, as the masses are still moving and can cause damage.

End position damping

The end stops and stop buffers installed in our linear modules protect the unit at low speed (commissioning). They are definitely not intended to completely protect the unit against damage at high speed and/or with a large mass.

9 Shutdown

WARNING



Risk of injury to personnel or damage to other components from falling components.
Only authorised technical personnel may operate the linear unit.

1. Cut the power to the machine/line.
2. Dismantle the drive from the linear unit.
3. Detach the linear unit from the machine/line.

10 Maintenance

- All installed ball bearings are sealed and maintenance-free.
- Remove excessive dust and dirt from the cover band and other components of the linear unit on a regular basis.
- Relubricate the thread drives of the linear axes on a regular basis.

10.1 Lubrication

Influencing factors The following factors are key to determining the exact lubrication intervals required:

- Loading
- Velocity
- Motion
- Operating temperature
- Degree of dirtying

Short lubrication intervals Short lubrication intervals are necessary:

- where there is susceptibility to dust and damp;
- under major loading;
- when running at high velocity (up to V_{\max});
- when running over short travel distances.

Initial lubrication

☛ Carry out an initial lubrication after starting up the unit for the first time. A basic lubrication was applied at the factory.

Refer to the lubrication regulations on the following pages.

Lubrication points on linear units (not Delta 90 as lubricated for life)




Figure 9: Possible lubrication points (1) on the carriage

The categories, quantity and positions of lubrication point depend on the model of linear unit. The categories of lubrication point are identified by the markings S, F on the unit.



There is a separate lubrication schedule for each lubrication point category.

Lubrication point category	Lubrication for...	Lubricant
S	Spindle	Grease
F	Guide elements	Grease

Lubrication method

Lubrication should, as far as possible, take place while the unit is running, so that the grease is distributed evenly and no pressure is built up.

Schedule for lubrication point S (for ball screw drive)

BSD* type	Lubrication intervals at roll-overs	Grease quantity [cm³] per ball screw nut	Grease type	
1205	25.000.000**	0.60	Greases to DIN 51825-KP2N-20, e.g. Klüberplex BE 31-102	
1210		0.60		
1605		1.70	 If other greases are used, pay attention to manufacturers' specifications!	
1610		1.80		
1620		1.90		
2005		2.00		
2020		2.30		 Greases containing solid lubricant (e.g. graphite, MoS2) must not be used!
2050		4.50		
2505		2.60		
2510		3.40		
2525		3.10		
2550		4.80		
3205		4.20		
3210		13.10		
3220		8.40		
3232		5.30		
3240		3.00		
4005	15.000.000**	5.30		
4010		15.40		
4020		10.20		
4040		9.50		
<div><div>*BSD = Ball Screw Drive</div><div>** Or at least 2x per year. The lubrication interval depends on the ambient temperatures and on the loading (see figure 9). Relubrication "in motion"!</div></div>				

Schedule for lubrication point F (for linear guide)

Carriage size	Lubrication interval	Grease quantity [cm ³] per carriage	Grease type
15 with ball chain	approx. 5,000 km*	approx. 0.4	Greases to DIN 51825-KPE1R-20, e.g. Klüberplex BE 31-102 ☛ If other greases are used, pay attention to manufacturers' specifications! ☛ Greases containing solid lubricant (e.g. graphite, MoS ₂) must not be used!
20 with ball chain		approx. 0.6	
25(L) with ball chain		approx. 1.2	
30 with ball chain		approx. 1.5	
35 with ball chain		approx. 1.7	
15 without ball chain	approx. 2,000 km*	approx. 0.8	
20 without ball chain		approx. 1.4	
25(L) without ball chain		approx. 2.8	
30 without ball chain		approx. 4.4	
35 without ball chain		approx. 4.4	

* Or at least 2 x per year. The lubrication interval depends on the ambient temperatures and on the loading (see figure 9). Relubrication "in motion"!





Figure 10: Relubrication intervals for the linear guidance system with recirculating linear ball bearings

10.2 Replacing cover bands

☛ To preserve the optimum running of the linear unit and prevent it from being damaged during operation, take care that no foreign bodies penetrate the base profile or other linear unit components during installation and assembly.

☛ Do not damage the standard parts (screws, pins, etc.) or the dismantled components; they will be refitted.

☛ If cover bands are worn, also replace the band guide elements. If cover bands are damaged, check the band guide elements for wear and replace them only as necessary.



Key	1	Carriage
	2	Clamp fittings
	3	Cover band

Figure 11: Cover bands based on the example of the Delta 200 linear unit

Procedure


1. Move the carriage into the middle and remove it.
Caution! Do not rotate the carriage. It must be refitted in the same position!

✎ Do not lose the O-rings fitted on the lubricating apertures on the underside of the carriage (not Delta 90).

2. Detach the clamp fittings from the ends of the cover band and remove the cover band.

3. Check the band guide elements such as the press rollers (a), lifting rollers (b) and locating pins for wear.

- If the cover band is worn, be sure also to replace the band guide elements. Worn guide elements will damage the new cover band.
- If the cover band is damaged, replace the band guide elements only if they are damaged. Do not interchange the press rollers (a), as they are different.



4. Insert the new cover band with its broader side (with the chamfered cutting edge) facing downwards and fix it at one end by the clamp fitting.
5. Carefully press the cover band into its guideway along its entire length until it audibly snaps into place. It must not stick out at any point, otherwise it will be damaged.
6. Stretch the cover band and fix it by the clamp fitting at the other end.
7. If the band guide elements are worn, mount the new elements on the underside of the carriage.
8. Make sure the O-rings are fitted on the lubricating apertures on the underside of the carriage and refit the carriage in the correct position.
9. To check that the carriage is correctly installed, run it slowly from one end of the linear unit to the other, ensuring the cover band is held all the time in its guideway.